

Configuration Cisco / LinkSys PAP2 for XeloQ / Goandcall.com

Just configuring Line 1 + Line 2 (at Admin Login) is enough!
If port 5060 does not work on your LAN, try 6060 !

Good Luck! Any questions: mail to support@xeloq.com

SIPURA
technology, inc.

Sipura Phone Adapter Configuration

Info System SIP Regional **Line 1** Line 2 User 1 User 2 [User Login](#) basic | [advanced](#)

Line Enable:

SIP Settings
SIP Port:

Proxy and Registration
Proxy: Register:
Make Call Without Reg: Register Expires:
Ans Call Without Reg:

Subscriber Information
Display Name: User ID:
Password: Use Auth ID:
Auth ID:

Supplementary Service Subscription

Call Waiting Serv:	<input type="text" value="yes"/>	Block CID Serv:	<input type="text" value="yes"/>
Block ANC Serv:	<input type="text" value="yes"/>	Dist Ring Serv:	<input type="text" value="yes"/>
Cfwd All Serv:	<input type="text" value="yes"/>	Cfwd Busy Serv:	<input type="text" value="yes"/>
Cfwd No Ans Serv:	<input type="text" value="yes"/>	Cfwd Sel Serv:	<input type="text" value="yes"/>
Cfwd Last Serv:	<input type="text" value="yes"/>	Block Last Serv:	<input type="text" value="yes"/>
Accept Last Serv:	<input type="text" value="yes"/>	DND Serv:	<input type="text" value="yes"/>
CID Serv:	<input type="text" value="yes"/>	CWCID Serv:	<input type="text" value="yes"/>
Call Return Serv:	<input type="text" value="yes"/>	Call Back Serv:	<input type="text" value="yes"/>
Three Way Call Serv:	<input type="text" value="yes"/>	Three Way Conf Serv:	<input type="text" value="yes"/>
Attn Transfer Serv:	<input type="text" value="yes"/>	Unattn Transfer Serv:	<input type="text" value="yes"/>
MWI Serv:	<input type="text" value="yes"/>	VMWI Serv:	<input type="text" value="yes"/>

Audio Configuration
Preferred Codec: Silence Supp Enable:
Use Pref Codec Only: FAX CED Detect Enable:
DTMF Tx Method:

[User Login](#) basic | [advanced](#)

Copyright © 2003-2005 Sipura Technology. All Rights Reserved.

Klaar